



#### **TAU-TH-01** HYFIRE TAURUS HEAT DETECTOR

**QUICK START GUIDE** 

# TAURUS 🔊 By Hyfire





Unit B12a, Holly Farm Business Park, Honiley, Warwickshire, CV8 1NP T: +44 (0)1926 485282, E: info@hyfirewireless.co.uk, W: www.hyfirewireless.com



### TAU-TH-01 HYFIRE TAURUS HEAT DETECTOR

## QUICK START GUIDE

#### 8 7 LED SWITCH 1 The detector's LED will signal 4 times red. . Move the switch in the base of the detector to position 1. The detector's LED will blink few seconds green and then signal alternatively green / red 4 times. 9 10 SCREW LOCK · Secure the screw on the base to ensure there is • Ensure you replace the battery cover as this forms no unwanted removal using a M3 allen key. part of the detectors anti tamper protection and refit • Put the QR code available in the box either on the detector locating it into the base twisting clockwise. the system map or on the dedicated pages at the end of translator or expander manual.

Unit B12a, Holly Farm Business Park, Honiley, Warwickshire, CV8 1NP T: +44 (0)1926 485282, E: info@hyfirewireless.co.uk, W: www.hyfirewireless.com TAURUS 🔊

By Hyfire